

Changing the Commander BN Time and Date

To Set Time and Date:

The Time and Date can only be changed at Station 10 and this updates all stations on system:

- Press the [SPKR] key
- Press the [SET] key
- Press the [CLOCK] key
- Dial the year (eg. 2000)
- Press [*]
- Dial in the Month & Day: Four digits – MMDD eg. 0828 = 28th September
- Press [*]
- Dial the day of the week 0 – Sunday 1 – Monday 2 – Tuesday 3 – Wednesday 4 Thursday 5 – Friday 6 – Saturday
- Press [*]
- Dial in the time in 24 hour time (four digits 1315 = 1.15pm)
- Time & Date eg. = 1.15pm Monday 28th September 2000
- Press [*]
- Press the [SPKR] key